

## **CRITICAL PARTS LIST**

1995–2004

PME Breaker Box	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004
196	-	-	-	-	-	S6289	S6289	S6289	80097	80097
206	-	-	-	-	-	S6289	S6289	S6289	80097	80097
216	-	-	-	-	-	S6289	S6289	S6289	80097	80097
210	-	-	-	-	-	S6289	S6289	S6289	80098	80098
211	-	-	-	-	-	-	-	-	-	80097
226	-	-	-	-	-	-	-	-	80097	80097

\* THE PDM PART# 120046 REPLACES ALL PME BREAKER BOXES USED UP THROUGH MODEL YEAR 2011 \*

Gateway Box	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004
196	-	-	-	-	-	-	-	-	SP-14-1246	SP-14-1246
206	-	-	-	-	-	-	-	-	SP-14-1246	SP-14-1246
216	-	-	-	-	-	-	-	-	SP-14-1246	SP-14-1246
210	-	-	-	-	-	-	-	-	SP-14-1246	SP-14-1246
211	-	-	-	-	-	-	-	-	-	SP-14-1246
226	-	-	-	-	-	-	-	-	SP-14-1246	SP-14-1246

\* #80037 can be used for Zero-Off only / # 70115 can be used for Perfect Pass and Zero-Off \*

\*Boats with gateway part# 70115 (GW0020) is now replaced by gateway conversion kit# SP-14-1246\*

ALL TEAM BOATS RECEIVE THE LINC SYSTEM (REPLACES THE GATEWAY BOX)

<b>Steering Cable</b>	<b>1995</b>	<b>1996</b>	<b>1997</b>	<b>1998</b>	<b>1999</b>	<b>2000</b>	<b>2001</b>	<b>2002</b>	<b>2003</b>	<b>2004</b>
196	S2205	S2205	S2205	90590	90590	90590	90590	90590	90590	90590
206	S2205	S2205	S2205	90590	90590	90590	90590	90590	90590	90590
216	S2205	S2205	S2205	90590	90590	90590	90590	90590	90590	90590
210	S2205	S2205	S2205	90590	90590	90590	90590	90590	90590	90590
211	-	-	-	-	-	-	-	-	-	90590
226	-	-	-	-	-	-	-	-	90545	90545





